

**Oster**®/MD

*User Manual* **Waffle Maker**

*Manuel d'Instructions* **Gaufrier**

**MODELS  
MODÈLES**

**CKSTWF2000-033**



*Visit us at [www.oster.ca](http://www.oster.ca)*

P.N. 165602

# IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following:

## READ ALL INSTRUCTIONS BEFORE USE

- Do not touch hot surfaces, use the handles.
- To protect against electric shock, do not place cord, plug or appliance in water or any other liquid.
- Close supervision is always necessary when this or any appliance is used by or near children.
- To disconnect, remove plug from electrical outlet.
- Unplug from outlet when not in use and before cleaning. Allow to cool before cleaning the appliance.
- Do not operate this or any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Return appliance to an Authorized Service Center for examination, repair or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause fire, electrical shock or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, in a heated oven or in a microwave oven.
- Do not use the appliance for other than intended use.
- When using this appliance, provide adequate air space above and on all sides for air circulation. On surfaces where heat may cause a problem, an insulated hot pad is recommended.
- Do not leave unit unattended during use.

## THIS UNIT IS FOR HOUSEHOLD USE ONLY

### EXTENSION CORD USE

A short power-supply cord is provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord. An extension cord may be used if care is exercised in its use. If an extension cord is used, the electrical rating of the cord must be at least as great as the electrical rating of the appliance. The extension cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over unintentionally.

### SPECIAL INSTRUCTIONS

This appliance has a grounded 3-prong electrical plug. It must be plugged only into a properly grounded 3-prong outlet. Do not modify the plug in any way.

## SAVE THESE INSTRUCTIONS

## WELCOME

Congratulations! You are now the owner of an OSTER® Waffle Maker.

Your new appliance will surely make crispy, hot, golden waffles in just minutes for a quick meal anytime of the day.

Prepare waffles for breakfast or brunch and pile them high with fresh fruits, whipped cream or just plain butter and warmed syrup.


Even desserts are more exciting with piping hot Brownie Waffles topped with ice cream, sauce toppings, chopped nuts and whipped cream.

Your OSTER® Waffle Maker is thermostatically controlled to help you prepare waffles to perfection. Your unit is portable so you can make waffles in your kitchen or right at the table. The non-stick grids make clean-up easy. We know that you will love your new OSTER® Waffle Maker. It's a great addition to any kitchen.

## HOW TO USE YOUR OSTER® WAFFLE MAKER

### PREPARING YOUR WAFFLE MAKER FOR USE

1. Open unit by lifting the upper handle.
2. Before using for the first time, clean cooking plates with cloth or sponge, dampened with hot, soapy water. **DO NOT IMMERSE UNIT IN WATER.** Rinse with dampened cloth or sponge and wipe dry.
3. When using for the first time, “season” the grids by rubbing lightly with cooking oil. Should sticking occur in later usage, re-season your unit.



### PREPARING WAFFLES

1. Close unit and plug into outlet. Use only voltage specified on bottom of unit. The On light (Red) (⚡) will come on. The Ready to Cook light (Green) (☑) will come on immediately when in the OFF (○) position.

**CAUTION:** Touch unit only by handles during use or directly after use.

2. Temperature Control Dial settings range from min for light waffles to max for dark waffles. The Ready to Cook light (Green) (☑) will turn off while heating up.
3. The unit is ready for use when the Ready to Cook light (☑) comes on.
4. Open unit and pour approximately  $\frac{3}{4}$  cup waffle batter onto grids. For best results, pour batter in a circle around outer edge of waffle maker. (See Illustration) Close cover. It is very typical to have a small amount of batter run over grid and down unit. However, if an excessive amount of batter runs over, use less batter.
5. Cover will rise slightly as waffles begin to bake. Do not open cover while steam is escaping. Most waffle recipes bake in approximately 5 minutes on the low setting, 4- $\frac{1}{2}$  minutes on the medium setting and 4 minutes on the high setting. Waffles are generally done when steam no longer escapes from sides and front of unit.
6. When waffles are done, remove with a plastic fork or wooden tongs.  
**NOTE:** The Ready to Cook light (☑) may cycle on and off during cooking. This indicates that the thermostat is maintaining the unit at the proper cooking temperature.
7. Close cover and wait for Ready to Cook light to come on before preparing another batch of waffles.

## CARE AND CLEANING

1. Unplug and allow unit to cool before cleaning.
2. Clean waffle grids with cloth or sponge dampened with hot, soapy water. **DO NOT IMMERSER UNIT IN WATER.** Rinse with dampened cloth or sponge and wipe dry.
3. To remove cooked-on foods, use a nylon scrub pad or non-abrasive cleanser. A steel wool pad or abrasive cleaners will damage the non-stick surface.
4. Store in closed position.
5. Any servicing required should be performed only by an authorized service facility.
6. This appliance is for household use only.

## HINTS FOR TASTY WAFFLES

1. Do not over-mix waffle batter. Beating egg whites separately and folding them gently into the batter surely will create a lighter, crispier waffle.
2. Completely bake waffles before removing from unit.
3. Don't open the Waffle Maker while steam is escaping from sides and front of the unit.
4. Why not freeze prepared waffles for those busy days ahead? Just bake the waffles as directed. Cool on a wire rack and wrap in moisture-proof paper or plastic. Quickly reheat in your toaster oven, broiler or microwave oven.

## WAFFLE MAKING

Prepare your own waffles from scratch with any of the OSTER® Waffle Maker recipes listed on the following pages, or use any of your own family favorites. For those busy days, why not have a prepared mix handy for a meal in a matter of minutes?

## CREATIVE WAFFLES

Let your imagination be your guide to many exciting and tasty meals with your OSTER® Waffle Maker. Here are just a few suggestions:

## BREAKFAST AND BRUNCH

Top crispy waffles with:

Butter, Syrup, Honey, Molasses, Apple Butter, Pie Filling,  
Whipped Cream, Yogurt, Fruit Preserves, Fresh Fruit

## DESSERT

Serve dessert waffles hot or cold. Prepare a richer batter such as Belgian-Style Waffles or Chocolate Brownie Waffles. Top with your favorite sweet and tasty ingredients which might include:

Sweetened Fresh Berries, Ice Cream, Powdered Sugar,  
Chopped Nuts, Sundae Sauces, Fruit Yogurt

# RECIPES

## QUICK WAFFLES

3 eggs	2 cups flour
1 cup milk	½ tsp. salt
½ cup melted butter or margarine	1 Tbsp. baking powder
1 Tbsp. vanilla (optional)	2 tsp. sugar

Beat whole eggs in a bowl until thick. Beat milk, melted butter and vanilla into eggs. In a separate bowl, combine remaining ingredients. Sift into egg mixture, and mix well. Bake as directed. YIELD: 6–8 WAFFLES

**Variation: Cinnamon – Apple.** Add 1 apple peeled and shredded, 1 tsp. vanilla and ½ tsp. cinnamon to batter.

## BLENDER CORNMEAL WAFFLES

*Enjoy a crisp waffle that's prepared in seconds*

1 egg (or equivalent)	2 Tbsp. (30 ml) cornmeal
¾ cup (200 ml) milk*	2 tsp. (10 ml) baking powder
¼ cup (50 ml) vegetable oil	2 tsp. (10 ml) sugar
1 cup (250 ml) all-purpose flour	¼ tsp. (1 ml) salt

\*low-fat or skim milk may be used

Preheat Waffle Maker. Put all ingredients into blender container. Cover and process at a medium-high speed until dry ingredients are moistened. Do not over-blend. Pour ¾ cup (200 ml) batter over grids. Close Waffle Maker. Bake until steam no longer escapes, about 3–5 minutes. Repeat. Serve while hot with warmed syrup. YIELD: 3 WAFFLES

## EXTRA-SPECIAL WHOLE WHEAT WAFFLES

*Feed the gang with these at Sunday Brunch*

1 cup (250 ml) milk*	3 eggs (or equivalent)
1 cup (250 ml) water	1 package (1/4 ounce or 7 g) active dry yeast
¼ cup (50 ml) butter or margarine	
¼ cup (50 ml) honey	½ tsp. (2 ml) salt

2 2/3 cups (650 ml) whole wheat flour

\*low-fat or skim milk may be used

Heat milk, water, butter and honey at 120°F (48°C). In large mixing bowl, combine flour, eggs, yeast, salt and warmed milk mixture. Mix at low to moisten, then medium-high for 1 minute. Cover and refrigerate several hours or overnight, stirring occasionally.

Preheat Waffle Maker. Pour ¾ cup (200 ml) over grids. Close waffle maker, bake until steam no longer escapes, about 3–5 minutes. Repeat. Serve while hot with your favorite topping. YIELD: 7 WAFFLES

## LIGHT 'N CRISP WAFFLES

2 egg yolks	½ tsp. (2 ml) salt
2 cups (500 ml) milk	1/3 cup (75 ml) oil
2 cups (500 ml) all-purpose flour	2 egg whites, stiffly beaten
1 Tbsp. (15 ml) baking powder	

Preheat Waffle Maker. Put all ingredients, except egg whites, in a large mixing bowl. Beat on low until moistened. Increase to medium, mix until smooth. By hand, gently fold in beaten egg whites. Pour ¾ cup (200 ml) batter over grids. Close Waffle Maker, bake until steam no longer escapes, about 3–5 minutes. Repeat. Serve while hot with your favorite topping.

YIELD: 5 WAFFLES

## VARIATIONS

**Pecan or Macadamia Nut Waffles:** Sprinkle 1 Tbsp. (15 ml) finely chopped pecans or macadamia nuts over preheated waffle grids. Pour  $\frac{3}{4}$  cup (200 ml) batter over nuts and close Waffle Maker. Bake as directed.

**Bacon Waffles:** Cook bacon strips. Pour  $\frac{3}{4}$  cup (200 ml) batter over waffle grids. Cut 1 strip bacon in half, lay over batter and close Waffle Maker. Bake as directed.

**Cheese Waffles:** Fold in  $1\frac{1}{2}$  cups (375 ml) shredded cheddar cheese into batter. Bake as directed. Serve with syrup or your favorite creamed entrée.

**Blueberry Waffles:** Fold 2 cups (500 ml) fresh blueberries into batter. Pour  $\frac{3}{4}$  cup (200 ml) batter over grids. Bake until golden.

**Chocolate Chip Waffles:** Fold 1 cup (250 ml) chocolate chips into batter. Bake as directed.

## LEMON SWEET WAFFLES

1 cup butter or margarine (softened)	$3\frac{1}{4}$ cups flour
$1\frac{1}{2}$ cups sugar	1 packet of vanilla sugar
2 eggs	$1\frac{3}{4}$ cups water
$\frac{1}{8}$ tsp. baking powder	grated rind of 1 lemon

In a large bowl, beat butter, sugars and eggs together. Add all dry ingredients along with water and lemon rind, and blend until smooth. Pour approximately  $\frac{3}{4}$  cup batter into waffle iron. Bake as directed.

YIELD: 8-10 WAFFLES

## ALOHA DESSERT WAFFLES

*A pretty dessert that is guaranteed to please your guests*

8 prepared Macadamia Nut Waffles	1 can (6 oz. or 170 g) frozen orange juice concentrate, thawed
1 cup (250 ml) sugar	$\frac{1}{2}$ cup (125 ml) flaked coconut
3 Tbsp. (45 ml) cornstarch	$\frac{1}{3}$ cup (75 ml) Maraschino cherries, chopped
1 can (8 oz. or 277 g) crushed pineapple, drained reserving juice	$\frac{1}{4}$ cup (50 ml) 150 Proof rum
Cold water	Vanilla ice cream

In a large sauté pan, combine sugar and cornstarch. Measure pineapple juice and enough cold water to equal  $1\frac{1}{4}$  cups (300 ml). Combine water mixture, orange juice and sugar mixture. Cook over medium heat until thickened, stirring constantly. Add coconut, cherries and pineapple. Heat through. Keep warm on low heat. Slowly pour rum over top of mixture. Carefully ignite. Place a scoop of vanilla ice cream over each waffle.

When flame dies, spoon sauce over ice cream. Serve immediately. YIELD: 5 WAFFLES

## CHOCOLATE BROWNIE WAFFLES

*Here's a no-fuss dessert idea!*

$\frac{1}{4}$ cup (50 ml) shortening or oil	1 Tbsp. (15 ml) baking powder
$\frac{2}{3}$ cup (150 ml) sugar	$\frac{1}{4}$ tsp. (1 ml) salt
2 squares (1 ounce or 28 g each) baking chocolate, melted	$1\frac{1}{4}$ cups (300 ml) milk
3 egg yolks	$\frac{1}{2}$ tsp. (2 ml) vanilla
$1\frac{1}{2}$ cups (375 ml) all-purpose flour	$\frac{1}{2}$ cup (125 ml) chopped nuts
	3 egg whites, stiffly beaten

Preheat Waffle Maker. In a large mixing bowl, cream shortening and sugar at medium-low until fluffy. Add chocolate and egg yolks. Beat well. Add milk alternately with combined dry ingredients. Mix well. Add vanilla and nuts. By hand, gently fold in beaten egg white. Pour  $\frac{3}{4}$  cup (200 ml) batter over grids. Close Waffle Maker and bake until steam no longer escapes, about 3-5 minutes. Waffle will crisp as it cools. Repeat. Serve hot or cold with vanilla ice cream, chocolate syrup and chopped walnuts or pecans.

YIELD: 6 WAFFLES

## ***One-Year Limited Warranty***

Sunbeam Products, Inc., or if in Canada, Sunbeam Corporation (Canada) Limited (collectively "Sunbeam") warrants that for a period of one year from the date of purchase, this product will be free from defects in material and workmanship. Sunbeam, at its option, will repair or replace this product or any component of the product found to be defective during the warranty period. Replacement will be made with a new or remanufactured product or component. If the product is no longer available, replacement may be made with a similar product of equal or greater value. This is your exclusive warranty.

This warranty is valid for the original retail purchaser from the date of initial retail purchase and is not transferable. Keep the original sales receipt. Proof of purchase is required to obtain warranty performance. Sunbeam dealers, service centers, or retail stores selling Sunbeam products do not have the right to alter, modify or any way change the terms and conditions of this warranty.

This warranty does not cover normal wear of parts or damage resulting from any of the following: negligent use or misuse of the product, use on improper voltage or current, use contrary to the operating instructions, disassembly, repair or alteration by anyone other than Sunbeam or an authorized Sunbeam service center. Further, the warranty does not cover: Acts of God, such as fire, flood, hurricanes and tornadoes.

### **What Are the Limits on Sunbeam's Liability?**

Sunbeam shall not be liable for any incidental or consequential damages caused by the breach of any express, implied or statutory warranty or condition.

Except to the extent prohibited by applicable law, any implied warranty or condition of merchantability or fitness for a particular purpose is limited in duration to the duration of the above warranty.

Sunbeam disclaims all other warranties, conditions or representations, express, implied, statutory or otherwise.

Sunbeam shall not be liable for any damages of any kind resulting from the purchase, use or misuse of, or inability to use the product including incidental, special, consequential or similar damages or loss of profits, or for any breach of contract, fundamental or otherwise, or for any claim brought against purchaser by any other party.

Some provinces, states or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusion may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights that vary from province to province, state to state or jurisdiction to jurisdiction.

### **How to Obtain Warranty Service**

In the U.S.A.

If you have any question regarding this warranty or would like to obtain warranty service, please call 1.800.334.0759 and a convenient service center address will be provided to you.

In Canada

If you have any question regarding this warranty or would like to obtain warranty service, please call 1.800.667.8623 and a convenient service center address will be provided to you.

In the U.S.A., this warranty is offered by Sunbeam Products, Inc., located in Boca Raton, Florida 33431. In Canada, this warranty is offered by Sunbeam Corporation (Canada) Limited, located at 20 B Hereford Street, Brampton (Ontario) L6Y 0M1.

**PLEASE DO NOT RETURN THIS PRODUCT TO ANY OF THESE ADDRESSES OR TO THE PLACE OF PURCHASE.**



For product questions contact:  
Sunbeam Consumer Service

USA : 1.800.334.0759  
Canada : 1.800.667.8623  
[www.oster.ca](http://www.oster.ca)

© 2013 Sunbeam Products, Inc. doing business as Jarden Consumer Solutions.  
All rights reserved. In Canada, imported and distributed by Sunbeam Corporation (Canada) Limited doing business as Jarden Consumer Solutions, 20 B Hereford Street, Brampton, Ontario L6Y 0M1.

Pour les questions de produit:  
Sunbeam Consumer Service

États-Unis : 1.800.334.0759  
Canada : 1.800.667.8623  
[www.oster.ca](http://www.oster.ca)

© 2013 Sunbeam Products, Inc. faisant affaires sous le nom de Jarden Consumer Solutions. Au Canada, importée et distribuée par Sunbeam Corporation (Canada) Limited faisant affaire sous le nom de Jarden Consumer Solutions, 20 B Hereford Street, Brampton (Ontario) L6Y 0M1.

GCDS-OST28894-JC

Printed in China

Imprimé en Chine